



1 Remove solenoid valve



2 Pump **without** patented system



3 Fit solenoid valve in new pump

